STANDARD PREVENTIVE MAINTENANCE GUIDELINE



Syst	em	A
on	off	Guideline
	D	aily Pre-trip Inspection and Maintenance
	Х	Check condition and tension of drive belts.
Х		Confirm all evaporator and condenser fans are operating.
Х		Check for unusual noises at the engine, evaporator, and condenser.
Х		Run system for 5 minutes.
	٧	Veekly Inspection
		Conduct Daily Pre-trip Inspection.
	Х	Check air filter- clean or replace as needed.
Х		Check for sufficient air flow at evaporator air outlet. Inspect return air filter if air flow is less than normal.
Х		Check set point temperature on digital thermostat to ensure proper cooling.
	Х	Check condenser and evaporator coils for cleanliness - clean if needed.
Χ		Check for water dripping from the evaporator or air ducts.
	N	Ionthly Inspection
		Conduct Weekly Inspection.
		Clean or replace return air filter.
	Х	Check compressor belt for wear and proper tension.
Х		Confirm sufficient battery voltage.
		Inspect wiring harness and relay board to ensure electrical integrity.
	Х	Inspect kazoo valves on all drain lines.
	C	luarterly Inspection
		Conduct Monthly Inspection.
	$\overline{}$	Inspect all components including evaporator and condenser motors.
	Х	Check securement and condition of hoses and harness.
Х		Check for proper drainage of evaporator drain lines.
		Check all mounting hardware on evaporator, condenser and compressor, tighten as necessary.
	S	emi-Annual Inspection
		Perform quarterly and monthly inspections.
		Open bus heater valves (winter), if needed.
		Close bus heater valves (spring), if needed.
		Remove or install optional winter guard kit, as needed.
	Α	nnual Inspection
	· ·	Conduct Quarterly Inspection.
	X	Clean evaporator and drain pan.
X		Perform manifold gauge check.
Х		Check voltage at motors, replace if necessary.
		Check all hose connections tighten and/or secure as necessary.
		Check and tighten any connection at the electrical boards and at the battery. Clean if needed.
	Х	Remove and Replace compressor belt (at customers expense).